

Rubber Off Instructions

1. Start engine and get the exhaust hot.
2. When the pipes are hot use a cotton swab to install cleaner.
3. Wipe off with a cloth. Be careful not to burn your fingers.
4. It may take a couple of applications to remove all burnt rubber or oil off of exhaust pipe.
5. Cleaner can be applied to cold pipes, just let product soak for 5-10 minutes at a time until removed.
6. After all material has been removed you may install a chrome wax to remove residue and bring pipes to a nice shine.

IMPORTANT: Do not get on hands. Use safety glasses. Do not get on painted parts.

sohotbikes.com
800-893-6916

DANGER:

CONTAINS SODIUM HYDROXIDE. Avoid eye and skin contact. If eye contact occurs, flush eyes with running water for at least 15 minutes. If irritation persists, call a physician. If skin contact occurs, flush skin with water. Do not take internally. If swallowed, do not induce vomiting. Drink large amounts of water and call a physician immediately. Wash hands after using. MSDS sheets available upon request. We assume no liability for damages of any kind and the user accepts the product "as is" and without warranties, expressed or implied.

MEDICAL EMERGENCY HOTLINE 1-800-246-2890